IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric hazard and injury to persons, including the following:

1. Read all instructions before operating.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plug or appliance itself in water or other liquids.
4. Close supervision is necessary when appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Bring the appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into wall outlet. To disconnect, turn any control to OFF position, then remove plug from wall outlet.
12. Oversized foods or metal utensils must not be inserted in the appliance as they may cause a fire or risk of electrical shock.
13. A fire may occur if the appliance is covered or touching flammable material including curtains, draperies, walls and the like when in operation.
14. Do not clean with metal scouring pads. Pieces can break off
the pad and touch electrical parts, involving a risk of electrical shock.
15. Extreme caution should be exercised when using containers constructed of other material other than metal or glass.
16. Do not store any materials other than manufacturers recommended accessories in this oven when not in use.
17. Do not place any of the following materials in the oven: Paper, cardboard, plastic and the like.

SAVE THESE INSTRUCTIONS
THIS PRODUCT IS FOR HOUSEHOLD USE ONLY

Short Cord Purpose

1) A short power-supply cord is provided to reduce risks of injuring yourself from becoming entangled in or tripping over a longer cord.
2) Longer extension cords are available and may be used if you exercise caution during use.
3) If a longer cord is used please note the following:
- The marked electrical rating of the extension cord should be at least as 13A, 125V, 1625W .
- The longer cord should be arranged so that it will not drape over the counter top of tabletop where it can be pulled on by children or tripped over accidentally.

Polarized Plug

If this appliance has a polarized plug (meaning one blade is wider than the other one), please follow the below instructions: To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only in one direction. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
This appliance is intended for Household Use Only.

Operating Instructions

1. Before plugging in your new burner, check to see that the electric circuit is not overloaded with other appliances. This unit should always be operated on a separate 120Volt AC outlet.
2. Be certain that your unit is resting on a leveled flat countertop. Avoid using pans that are unstable and easily tipped.
3. Place pan on heating element.
4. Turn the control knob from the "OFF" position to the desired thermostat position of "LO", "MED", or "HIGH".
5. The heating element will energize and heating will begin immediately.
6. The whole burner except the control knob will become hot. Do not touch while in use.
7. When cooking is complete, turn control knob back to "OFF" position.
8. If the burner is not to be in use for a long period of time, it is highly recommended to unplug the unit from the outlet. This prevents any accidental burns or injury.

Cleaning Instructions

1) Make sure Timer is set to OFF position and power cord is unplugged.
2) Never immerse unit into water.
3) For easy cleaning of the drip pan, the heating element is designed so that one end can be lifted up. Wipe clean the drip pan area with damp towel or sponge. Do not attempt to remove the entire heating element.
4) Use damp towel or sponge to clean the surface of burner, the chrome burner ring, the drip pan, and the base.
5) Never use harsh abrasives or steel wool pads on any part of unit.